Synth

Korg microKORG2

69 parameters · 12 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels
Send on the Global MIDI channel. Timbre 2 has a channel of its own, so the same chart reaches the second timbre there.

Before you send
Set GLOBAL > MIDI FILTER > Control Change to Enable. With the filter closed the microKORG2 ignores every number on this page.

Pitch & Voice	6	
Porta Time		5
Porta Mode	switch	65
Transpose		35
Fine Tune		36
Uni Detune		33
Uni Spread		34

Osc 1	5
Wave	8
Shape	9
Osc Mod	15
Semitones	16
Fine Tune	17

Osc 2	5
Wave	18
Shape	19
Osc Mod	20
Semitones	21
Fine Tune	22

Osc 3	4
Wave	48
Shape	49
Semitones	51
Fine Tune	52

Mixer	6
Osc 1 Lvl	23
Osc 2 Lvl	24
Osc 3 Lvl	25
Noise Lvl	26
Noise Type	29
Noise Color	30

Filter	5
Cutoff	74
Resonance	71
Drive	83
Type	27
Keytrack	28

Envelopes	10
Amp Attack	73
Amp Decay	75
Amp Sustain	70
Amp Release	72
Amp Velo	79
Flt Attack	85
Flt Decay	86
Flt Sustain	87
Flt Release	88
Flt EG Int	84

LFO & Patch	12
LFO1 Freq	90
LFO1 Wave	89
LFO1 Smooth	91
LFO2 Freq	76
LFO2 Wave	102
LFO2 Delay	92
Patch 1	103
Patch 2	104
Patch 3	105
Patch 4	106
Patch 5	107
Patch 6	108

Mod FX	3
Mod Rate	12
Mod Depth	111
Mod Out	112

Delay	4
Dly Time	13
Dly Depth	113
Dly Low Cut	114
Dly Extra	115

Reverb	4
Rev Time	14
Rev Depth	116
Rev Damping	117
Rev Extra	118

EQ	5
Low Freq	95
Low Gain	110
High Freq	94
High Gain	109
Feedback	93

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia