Synth

Korg multi/poly

18 parameters · 5 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

Set the Global MIDI channel under Utility > MIDI & USB and send there.

Mod Knobs

CC 24 to 27 are the four Mod Knobs. Each Program decides what its knobs do, so the same number moves a different parameter in a different sound.

Mod Knobs	4
Knob 1	24
Knob 2	25
Knob 3	26
Knob 4	27

Kaoss	4	
Kaoss X		18
Kaoss Y		19
Pad Touch	switch	20
Kaoss Btn	switch	12

Performance	7	
Mod Wheel		1
Expression		11
Volume		7
Pan		10
Damper	switch	64
Sostenuto	switch	66
Soft	switch	67

Global	1
Scale Sel	9

Panic	2	
All Off	switch	120
Reset Ctrl	switch	121

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia