Effect

Korg NTS-3

35 parameters · 6 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

One global channel, 1 by default. The four effect slots are addressed by separate CC numbers, not by separate channels.

Effect select is scaled

Select on CC 80 to 83 is not an index. The value is divided by the number of effects installed, so the same number picks a different effect once you load user effects.

Good to know

The switches follow Korg's documented threshold: 64 and up is on. Korg's own file prints a wrong hex value next to Total FX Depth. CC 14 fits the pattern of every other row in the table, but it is worth confirming on your unit.

Total FX	5
Pad X	12
Pad Y	13
Depth	14
Touch (switch)	102
Freeze (switch)	103

FX 1	7
Pad X	16
Pad Y	17
Depth	18
Select	80
On (switch)	106
Touch (switch)	104
Freeze (switch)	105

FX 2	7
Pad X	20
Pad Y	21
Depth	22
Select	81
On (switch)	110
Touch (switch)	108
Freeze (switch)	109

FX 3	7
Pad X	24
Pad Y	25
Depth	26
Select	82
On (switch)	114
Touch (switch)	112
Freeze (switch)	113

FX 4	7
Pad X	28
Pad Y	29
Depth	30
Select	83
On (switch)	118
Touch (switch)	116
Freeze (switch)	117

Global	2
Volume	7
Input Mute (switch)	15

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia