Synth

# Korg volca bass

12 parameters · 4 sections · plain CC, no NRPN · transcribed from the maker's manual

### Channels

One global channel. If nothing responds, check that MIDI RX Short Message is On.

### MIDI only

Slide Time on CC 5, Expression on CC 11 and Gate Time on CC 49 have no knob on the machine. Korg flags them itself, and they are the best reason to put a controller on a volca bass. Octave on CC 40 is stepped: the travel of the knob picks one of six.

| Oscillator | 4 |
|---|---|
| VCO 1 | 43 |
| VCO 2 | 44 |
| VCO 3 | 45 |
| Octave | 40 |

| Filter and EG | 3 |
|---|---|
| Cutoff EG Int | 48 |
| EG Attack | 46 |
| EG Decay | 47 |

| LFO | 2 |
|---|---|
| Rate | 41 |
| Int | 42 |

| MIDI only | 3 |
|---|---|
| Slide Time | 5 |
| Expression | 11 |
| Gate Time | 49 |

**These controls as knobs on your iPhone or iPad**
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia