Drum machine

Korg volca beats

20 parameters · 3 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

One global channel for the whole machine. You set it by holding FUNC while powering on.

Before you send

MIDI RX Short Message has to be On in the global parameters. It is on from the factory, so this only matters if someone changed it.

Part level	10
Kick	40
Snare	41
Lo Tom	42
Hi Tom	43
Cl Hat	44
Op Hat	45
Clap	46
Claves	47
Agogo	48
Crash	49

PCM speed	4
Clap	50
Claves	51
Agogo	52
Crash	53

Shape	6
Tom Decay	56
CH Decay	57
OH Decay	58
Hat Grain	59
Stutter Time	54
Stutter Depth	55

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia