Drum machine

Korg volca kick

10 parameters · 3 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

One global channel. You set it by holding FUNC and MEMORY while powering on.

Before you send

If nothing responds, check that MIDI RX Short Message is On.

Pulse	2
Colour	40
Level	41

Resonator	3
Pitch	46
Bend	47
Time	48

Shape	5
Attack	42
Decay	43
Drive	44
Tone	45
Accent	49

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia