Drum machine

Roland TR-6S

32 parameters · 6 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

The basic channel is 10 by default, and Roland does not document which channel control changes land on.

Not a small TR-8S

Six instruments: kick, snare, low tom, hand clap, closed and open hat. The numbers they use match the same instruments on the TR-8S, but the chart was read from the TR-6S document. FILL IN TRIG and BEAT are absent because the chart marks them send only.

Tune	6
BD Tune	20
SD Tune	25
LT Tune	46
HC Tune	58
CH Tune	61
OH Tune	80

Level	6
BD Level	24
SD Level	29
LT Level	48
HC Level	60
CH Level	63
OH Level	82

FX	6
Master FX switch	15
FX Ctrl	19
Delay Level	16
Delay Time	17
Delay Fbk	18
Reverb Level	91

Decay	6
BD Decay	23
SD Decay	28
LT Decay	47
HC Decay	59
CH Decay	62
OH Decay	81

Ctrl	6
BD Ctrl	96
SD Ctrl	97
LT Ctrl	102
HC Ctrl	106
CH Ctrl	107
OH Ctrl	108

Global	2
Shuffle	9
Accent	71

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia