Drum machine

Roland TR-8S

53 parameters · 6 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

The basic channel is 10 by default. Roland does not document which channel control changes land on, so if a knob does nothing, try the machine's Pattern Ch.

Only what is received

Roland's chart also lists two AUTO FILL IN rows. It marks them as sent but not recognized, so they are left out: a knob that does nothing is worse than a missing one.

Tune	11
BD Tune	20
SD Tune	25
LT Tune	46
MT Tune	49
HT Tune	52
RS Tune	55
HC Tune	58
CH Tune	61
OH Tune	80
CC Tune	83
RC Tune	86

Decay	11
BD Decay	23
SD Decay	28
LT Decay	47
MT Decay	50
HT Decay	53
RS Decay	56
HC Decay	59
CH Decay	62
OH Decay	81
CC Decay	84
RC Decay	87

Level	11
BD Level	24
SD Level	29
LT Level	48
MT Level	51
HT Level	54
RS Level	57
HC Level	60
CH Level	63
OH Level	82
CC Level	85
RC Level	88

Ctrl	11
BD Ctrl	96
SD Ctrl	97
LT Ctrl	102
MT Ctrl	103
HT Ctrl	104
RS Ctrl	105
HC Ctrl	106
CH Ctrl	107
OH Ctrl	108
CC Ctrl	109
RC Ctrl	110

FX	6	
Master FX	switch	15
FX Ctrl		19
Delay Level		16
Delay Time		17
Delay Fbk		18
Reverb Level		91

Global	3
Shuffle	9
Accent	71
Ext In Level	12

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia