Synth

Sonicware LIVEN Ambient Ø

45 parameters · 6 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels
Pattern controls answer on the pattern channel. The rest belong to a layer and answer on that layer's channel.

Reverb and shimmer
Each layer has its own sends: To Reverb on CC 54 and To Shimmer on CC 55.

Pattern	9
Velocity	5
Tune All	20
FX Type	21
FX Speed	22
FX Amount	23
Reverb Type	24
Reverb	25
Ptn Level	26
Rnd Seq	27

Oscillator	6
Structure	28
Wave	29
Harmonic	30
Balance	31
Pitch	32
Detune	33

Mod and filter	8
Mod Shape	34
Mod	35
Depth	36
Filter Type	37
Filter Cutoff	38
Filter Reso	39
Amp Attack	40
Amp Release	41

LFO 1	5
Shape	42
Assign	43
Trig	44
Rate	45
Depth	46

LFO 2	5
Shape	47
Assign	48
Trig	49
Rate	50
Depth	51

Layer	12
Track Level	52
Track Pan	53
To Reverb	54
To Shimmer	55
Dice	56
Octave	57
Voice Mode	58
Voice Adj	59
Transpose	60
Random Step	61
Prm Lock	62
Track Mute	63

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia