Groovebox

Sonicware LIVEN Bass&Beats

47 parameters · 4 sections · plain CC, no NRPN · transcribed from the maker's manual

Three channels

The chart prints them as PT.CH, BA.CH and DR.CH: pattern, bass and drums.

Same numbers, two meanings

The bass track and the drum track read the same numbers as different parameters. CC 30 is Memory on the bass channel and Level Kick on the drum channel. Aim a control at the channel of the group it comes from.

Pattern	8	
Velocity		5
FX On/Off	switch	20
FX Type		21
FX Amount		22
Ptn Level		23
Ducking		24
Seq Mode		25
Line In to FX		26

Bass track	17
Memory	30
Assign1	31
Assign2	32
Dimension	33
Pitch Rate	34
Pitch Depth	35
Release & Gate	36
M.Gun	37
Bank	38
Sweep Speed	39
Sweep Range	40
Dice	41
Octave	46
Voice Mode	47
Glide	48
Sweep	49
Transpose	50

Drum track	17
Level Kick	30
Level Snare	31
Level Hat	32
Level Others	33
Time Kick1	34
Time Snare1	35
Time Hat1	36
Time EX1	37
Tune Kick1	38
Tune Snare1	39
Tune Hat1	40
Tune Hat2	41
Tune EX1	42
Tune EX2	43
Tune EX3	44
Tune EX4	45
Kit	51

Either track	5
Swing	52
Random Step	53
Prm Lock	54
Level	55
FX Send	56

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia