Synth

Yamaha reface CP

14 parameters · 2 sections · plain CC, no NRPN · transcribed from the maker's manual

Before you send
Turn MIDI Control on in the settings first.

An effect chain
Most of this map is the effect chain, which is what the panel of the reface CP is. Each effect has a switch, a depth and a rate or time.

Effects		11
TREMOLO/WAH Switch	switch	17
TREMOLO/WAH Depth		18
TREMOLO/WAH Rate		19
Drive		81
CHORUS/PHASER Switch	switch	85
CHORUS/PHASER Depth		86
CHORUS/PHASER Speed		87
D.DELAY/A.DELAY Switch	switch	88
D.DELAY/A.DELAY Depth		89
D.DELAY/A.DELAY Time		90
Reverb Depth		91

Play	3
Speed	10
Depth	15
Type	80

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia