Drum machine

Elektron Analog Rytm MKII

87 parameters · 12 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

Drum controls listen on the drum track's own MIDI channel, 1 to 12 by factory default. The groups marked **FX ch** (Delay, Reverb, Dist and Comp) listen on the separate FX track channel.

Machine parameters

Synth 1 to Synth 8 are CC 16 to 23. Each track runs a machine and the eight slots follow it, so the chart keeps the numbers instead of naming them.

Trig	7
Note	3
Velocity	4
Length	5
Synth Trig switch	11
Sample Trig switch	12
ENV Trig switch	13
LFO Trig switch	14

Euclidean	7
Pulse Gen 1	86
Pulse Gen 2	87
Euclid On switch	117
Rot Gen 1	89
Rot Gen 2	90
Track Rot	91
Boolean Op	88

Track	5
Track Level	95
Mute switch	94
Solo switch	93
Machine	15
Scene	92

Synth	8
Synth 1	16
Synth 2	17
Synth 3	18
Synth 4	19
Synth 5	20
Synth 6	21
Synth 7	22
Synth 8	23

Sample	8
Tune	24
Fine Tune	25
Bit Reduct	26
Slot	27
Start	28
End	29
Loop switch	30
Level	31

Filter	8
Attack	70
Decay	71
Sustain	72
Release	73
Frequency	74
Reso	75
Mode	76
Env Depth	77

Amp	8
Attack	78
Hold	79
Decay	80
Overdrive	81
Delay Send	82
Rev Send	83
Pan	10
Volume	7

LFO	8
Speed	102
Multiplier	103
Fade	104
Destination	105
Waveform	106
Start Phase	107
Trig Mode	108
Depth	109

Delay FX ch	8
Time	16
Pingpong switch	17
Width	18
Feedback	19
HP Filter	20
LP Filter	21
Rev Send	22
Mix Vol	23

Reverb FX ch	7
Predelay	24
Decay	25
Shelv Freq	26
Shelv Gain	27
HP Filter	28
LP Filter	29
Mix Vol	31

Dist FX ch	5
Amount	70
Symmetry	71
Delay OD	72
Delay Route switch	76
Rev Route switch	77

Comp FX ch	8
Threshold	78
Attack	79
Release	80
Makeup	81
Ratio	82
Sidechn EQ	83
Dry/Wet	84
Volume	85

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia