Synth

Elektron Digitone Keys

86 parameters · 12 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

The synth groups listen on the track channel: Track 1 to 4, or the AUTO channel for whichever track is active. The four groups marked **FX ch** (Chorus, Delay, Reverb and Master) listen on the separate FX channel.

Keys and pedals

Sustain is CC 64 and Sostenuto is CC 66, both in the Track group, so a pedal on another keyboard can hold notes on the Digitone Keys.

Track		4
Mute	switch	94
Track Level		95
Sustain	switch	64
Sostenuto	switch	66

Trig	5
Root	3
Velocity	4
Length	5
Porta Time	15
Porta On	switch 16

SYN1 FM	8
Algorithm	90
Ratio C	91
Ratio A	92
Ratio B	16
Harmonics	17
Detune	18
Feedback	19
Mix	20

SYN2 Env	8
A Attack	75
A Decay	76
A End	77
A Level	78
B Attack	79
B Decay	80
B End	81
B Level	82

Filter	10
Frequency	23
Resonance	24
Type	74
Attack	70
Decay	71
Sustain	72
Release	73
Env Depth	25
Base	26
Width	27

Amp	10
Attack	104
Decay	105
Sustain	106
Release	107
Drive	9
Pan	10
Volume	7
Chorus Snd	12
Delay Send	13
Reverb Snd	14

LFO 1	8
Speed	28
Multiplier	108
Fade	109
Dest	110
Waveform	111
Start Phase	112
Trig Mode	113
Depth	29

LFO 2	5
Speed	30
Multiplier	114
Dest	116
Waveform	117
Depth	31

Chorus FX ch	7
Depth	3
Speed	9
Highpass	70
Width	71
Delay Send	12
Reverb Snd	13
Mix Vol	14

Delay FX ch	8
Time	15
Pingpong	switch 16
Width	17
Feedback	18
Highpass	72
Lowpass	73
Reverb Snd	19
Mix Vol	20

Reverb FX ch	7
Predelay	21
Decay	74
Shelv Freq	75
Shelv Gain	22
Highpass	76
Lowpass	77
Mix Vol	23

Master FX ch		6
Overdrive		29
Pattern Vol		95
Chorus L/R		26
Delay L/R		27
Reverb L/R		28
Dual Mono	switch	83

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia