Groovebox

Elektron Model:Cycles

30 parameters · 7 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

Everything listens on the track's own channel, T1 IN to T6 IN. The FX group (delay time and feedback, reverb size and tone) listens on the separate FX IN channel.

One knob per idea

Color, Shape, Sweep and Contour are CC 16 to 19. They are the four knobs that shape every machine, and Machine itself is CC 70.

Machine	5	
Machine		70
Color		16
Shape		17
Sweep		18
Contour		19

Track	7	
Note		3
Pitch		65
Decay		80
Vol+Dist		7
Track Lvl		95
Pan		10
Mute	switch	94

Sends	2	
Delay Send		12
Reverb Send		13

Groove	2	
Swing		15
Chance		14

Playback	2	
Punch	switch	66
Gate	switch	67

LFO	8	
Speed		102
Multiplier		103
Fade		104
Destination		105
Waveform		106
Start Phase		107
Reset	switch	108
Depth		109

FX FX ch	4	
Delay Time		85
Delay FB		86
Reverb Size		87
Reverb Tone		88

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia