Groovebox

Elektron Model:Samples

29 parameters · 4 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

Track, Playback and LFO controls listen on each track's own channel, T1 IN to T6 IN, or on the AUTO channel for the active track. Delay and Reverb listen on the separate FX IN channel.

Switches

Loop is CC 17 and Reverse is CC 18. Both are switches, as are Mute on CC 94 and the LFO Reset on CC 108.

Track		15
Note		3
Mute	switch	94
Level		95
Pan		10
Pitch		16
Decay		80
Start		19
Length		20
Cutoff		74
Resonance		71
Delay Send		12
Reverb Snd		13
Vol + Dist		7
Swing		15
Chance		14

Playback		2
Loop	switch	17
Reverse	switch	18

LFO		8
Speed		102
Multiplier		103
Fade		104
Dest		105
Wave		106
Start Phase		107
Reset	switch	108
Depth		109

FX FX ch		4
Delay Time		85
Delay Fdbk		86
Reverb Size		87
Reverb Tone		88

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia