Groovebox

Elektron Octatrack MKII

78 parameters · 12 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

The audio track groups listen on that track's TRIG CHANNEL, or on the AUTO channel for the active track. The three groups marked **AUTO ch** belong to MIDI mode and listen on the AUTO channel only.

Effect slots

FX1 and FX2 are six parameters each, CC 34 to 39 and CC 40 to 45. What a number moves depends on the effect loaded in the slot, so the chart calls them Param 1 to 6.

Playback	6
PTCH	16
STRT	17
LEN	18
RATE	19
RTRG	20
RTIM	21

Amp	5
Attack	22
Hold	23
Release	24
Volume	25
Balance	26

LFO	6
Speed 1	28
Speed 2	29
Speed 3	30
Depth 1	31
Depth 2	32
Depth 3	33

FX1	6
Param 1	34
Param 2	35
Param 3	36
Param 4	37
Param 5	38
Param 6	39

FX2	6
Param 1	40
Param 2	41
Param 3	42
Param 4	43
Param 5	44
Param 6	45

Levels	4
Track lvl	46
Cue level	47
Pickup AB	57
Pickup CD	58

Perform	3
Crossfader	48
Scene A	55
Scene B	56

Track ctrl		6
Mute	switch	49
Solo	switch	50
Cue	switch	51
Track arm	switch	52
Recrdr arm	switch	53
All arm	switch	54

Mute & solo		16
M1 mute	switch	112
M2 mute	switch	113
M3 mute	switch	114
M4 mute	switch	115
M5 mute	switch	116
M6 mute	switch	117
M7 mute	switch	118
M8 mute	switch	119
M1 solo	switch	120
M2 solo	switch	121
M3 solo	switch	122
M4 solo	switch	123
M5 solo	switch	124
M6 solo	switch	125
M7 solo	switch	126
M8 solo	switch	127

MIDI note AUTO ch	8
Note	16
Velocity	17
Length	18
Note 2	19
Note 3	20
Note 4	21
Pitch bend	34
Aftertouch	35

MIDI arp AUTO ch		6
Transpose		22
Legato	switch	23
Mode		24
Speed		25
Oct range		26
Note len		27

MIDI LFO AUTO ch	6
Speed 1	28
Speed 2	29
Speed 3	30
Depth 1	31
Depth 2	32
Depth 3	33

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia