Drum machine

Elektron Syntakt

86 parameters · 11 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

Most controls listen on the track's own MIDI channel, or on the auto channel for the active track. Everything marked **FX ch** (Delay, Reverb, FX Trk and Ext In) listens on the separate FX Control channel.

Machine parameters

The Source group is Syn A to Syn H on CC 17 to 24. What each one does follows the machine loaded on that track, so the chart keeps the letters.

Track		3
Mute	switch	94
Trk Level		95
Ptn Mute	switch	110

Trig	7
Note	3
Velocity	4
Length	5
Filter Trig (switch)	13
LFO Trig (switch)	14
Porta Time	9
Porta On (switch)	65

Source	8
Syn A	17
Syn B	18
Syn C	19
Syn D	20
Syn E	21
Syn F	22
Syn G	23
Syn H	24

Filter	11
Cutoff	74
Reso	75
Filter Type	76
Attack	70
Decay	71
Sustain	72
Release	73
Env Depth	77
Env Delay	78
Base	26
Width	27

Amp	9
Attack	79
Hold	80
Decay	81
Sustain	82
Release	83
Del Send	84
Rev Send	85
Pan	10
Volume	7

LFO 1	8
Speed	102
Multiplier	103
Fade	104
Dest	105
Waveform	106
Phase	107
Trig Mode	108
Depth	109

LFO 2	8
Speed	112
Multiplier	113
Fade	114
Dest	115
Waveform	116
Phase	117
Trig Mode	118
Depth	119

Delay FX ch	8	
Time		21
Pingpong	switch	22
Width		23
Feedback		24
HPF		25
LPF		26
Rev Send		27
Volume		28

Reverb FX ch	7
Predelay	29
Decay	30
Shlv Freq	31
Shlv Gain	89
HPF	90
LPF	91
Volume	92

FX Trk FX ch	12
Drive	15
Cutoff	70
Reso	71
Filter Type	72
Env Depth	73
Env Delay	74
Filt Pan	93
Amp Decay	81
Amp Rels	83
Del Send	84
Rev Send	85
Volume	7

Ext In FX ch	5	
In LR		16
In Bal		17
In Del		18
In Rev		19
In Route	switch	20

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia