Groovebox

Elektron Tonverk

80 parameters · 12 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

Each track answers on its own MIDI channel: the audio tracks on 1 to 8, the buses on 9 to 12 and the send effects on 13 to 15. The Mix In group answers only on the Mix track's channel, 16.

Lettered slots

SRC 1, SRC 2, FLTR and both insert effects are pages of eight slots, lettered A to H. A slot moves whatever the machine or effect on that track puts there, so the chart keeps the letters.

Trig	5
Note	3
Velocity	4
Length	5
Porta time	9
Porta on switch	65

SRC 1	8
SRC1 A	16
SRC1 B	17
SRC1 C	18
SRC1 D	19
SRC1 E	20
SRC1 F	21
SRC1 G	22
SRC1 H	23

SRC 2	8
SRC2 A	24
SRC2 B	25
SRC2 C	26
SRC2 D	27
SRC2 E	28
SRC2 F	29
SRC2 G	30
SRC1 H*	31

FLTR	10
FLTR A	70
FLTR B	71
FLTR C	72
FLTR D	73
FLTR E	74
FLTR F	75
FLTR G	76
FLTR H	77
FLTR base	78
FLTR width	79

AMP	8
Attack	83
Hold	84
Decay	85
Sustain	86
Release	87
Overdrive	88
Pan	10
Volume	89

FX routing	4
Send 1	44
Send 2	45
Send 3	46
Route	47

Insert FX 1	8
FX1 A	48
FX1 B	49
FX1 C	50
FX1 D	51
FX1 E	52
FX1 F	53
FX1 G	54
FX1 H	55

Insert FX 2	8
FX2 A	56
FX2 B	57
FX2 C	58
FX2 D	59
FX2 E	60
FX2 F	61
FX2 G	62
FX2 H	63

MOD	7
LFO1 speed	102
LFO1 mult	103
LFO1 depth	104
LFO2 speed	105
LFO2 mult	106
LFO2 depth	107
Env depth	110

FX LFO	6
L1 speed	111
L1 mult	112
L1 depth	113
L2 speed	114
L2 mult	115
L2 depth	116

Track	2
Global mute switch	94
Track level	95

Mix In MIX ch	6
In A level	16
In A pan	17
In A route	18
In B level	20
In B pan	21
In B route	22

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia