Synth

Korg minilogue xd

55 parameters · 12 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

One channel for everything. Set the synth's global MIDI Ch in GLOBAL EDIT to the channel your controller sends on.

Before you send

Turn MIDI Rx CC to On in the global settings, or the minilogue xd will not react. This is not the first minilogue. That machine has a different map.

Voice	5
Mod Wheel	1
Portamento	5
Voice Depth	27
Voice Type	52
Damper switch	64

VCO 1	4
Wave	50
Octave	48
Pitch	34
Shape	36

VCO 2	7
Wave	51
Octave	49
Pitch	35
Shape	37
Sync switch	80
Ring switch	81
Cross Mod	41

Multi	4
Type	53
Sub Type	103
Shape	54
Shift Shp	104

Mixer	3
VCO 1	39
VCO 2	40
Multi	33

Filter	4
Cutoff	43
Resonance	44
Drive	84
Keytrack	83

Amp EG	4
Attack	16
Decay	17
Sustain	18
Release	19

EG	4
Attack	20
Decay	21
EG Int	22
EG Target	23

LFO	5
Wave	57
Mode	58
Rate	24
Int	26
Target	56

Mod FX	5
On switch	92
Type	88
Sub Type	96
Time	28
Depth	29

Delay	5
On switch	94
Type	89
Time	105
Depth	112
Dry/Wet	107

Reverb	5
On switch	95
Type	90
Time	114
Depth	115
Dry/Wet	110

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia