Synth

Korg NTS-1 mkII

30 parameters · 8 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

One global channel, 1 by default. If nothing responds, check that the global MIDI RX short message is on and that MIDI route is not set to USB only.

Type controls are steppers

Oscillator, filter, mod, delay and reverb Type walk a list instead of sweeping. Korg prints value bands for each one.

Left out

Korg publishes every continuous parameter as a 14 bit pair. The chart keeps the coarse half, which is what a 7 bit knob sends. The deep oscillator and effect edit parameters live on NRPN only.

Oscillator	5
Type	53
A	54
B	55
LFO Rate	24
LFO Depth	26

Filter	5
Type	42
Cutoff	43
Resonance	44
Sweep Depth	45
Sweep Rate	46

Envelope	5
Type	14
Attack	16
Release	19
Trem Depth	20
Trem Rate	21

Mod	3
Type	88
A	28
B	29

Delay	4
Type	89
A	30
B	31
Mix	33

Reverb	4
Type	90
A	34
B	35
Mix	36

Arp	3
Pattern	117
Intervals	118
Length	119

Global	1
Volume	7

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia