Synth

Korg volca fm2

13 parameters · 5 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

One global channel. You set it by holding MEMORY while powering on. If nothing responds, check that MIDI Short Message is On.

Two readings of CC 40

Transpose on CC 40 changes meaning with the machine's own TRANSPOSE NOTE switch. With it off the control moves whole octaves, with it on it moves semitones. The four envelope controls are centered on 64, so the middle of the knob is no change.

Modulator	2
Attack	42
Decay	43

Carrier	2
Attack	44
Decay	45

Voice	3
Algorithm	48
Transpose	40
Velocity	41

LFO	2
Rate	46
Pitch Depth	47

Arp and FX	4
Arp Type	49
Arp Div	50
Reverb	91
Chorus	93

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia