Synth

Korg volca keys

16 parameters · 5 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

One global channel. If nothing responds, check that MIDI RX Short Message is On.

Stepped controls

Voice on CC 40 picks poly, unison, octave, fifth, unison ring or poly ring across the travel of the knob. Octave on CC 41 picks one of six footings. Expression on CC 11 has no panel knob and is reachable only over MIDI.

Voice	5
Voice	40
Octave	41
Detune	42
Portamento	5
Expression	11

Filter	3
Cutoff	44
VCF EG Int	45
VCO EG Int	43

Envelope	3
Attack	49
Decay	50
Sustain	51

LFO	3
Rate	46
Pitch Int	47
Cutoff Int	48

Delay	2
Time	52
Feedback	53

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia