Synth

Moog Grandmother

23 parameters · 5 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels

A single MIDI channel for both send and receive, 1 by default. You choose 1 to 16 by pressing the F#0 key and then one of the first sixteen white keys.

What has no CC

The Grandmother is semi modular: the filter, the envelope, the mixer and the spring reverb are analog only and have no CC.

Modulation	2
Mod Wheel	1
Mod Rate	3

Oscillators	4
Osc 2 Freq	12
Osc 1 Octave	74
Osc 2 Octave	75
Osc 2 Sync switch	77

Glide	5
Glide Time	5
Glide On switch	65
Glide Type	85
Legato Glide switch	94
Gated Glide switch	103

Arp / Seq	7
Arp/Seq Rate	8
Arp/Seq Hold switch	69
Arp/Seq Play switch	73
Clock Div	90
Arp/Seq Mode	91
Arp Pattern	92
Arp Rng/Seq	93

Keyboard	5
Sustain Ped switch	64
KB Octave	89
Bend Up Amt	107
Bend Dn Amt	108
KB Transpose	119

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.
synthycraft.com/l/sequentia