Synth

Novation Bass Station II

62 parameters · 11 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels
The Bass Station II transmits and receives on MIDI channel 1 by default. Change it with Function and the upper G# key.

Switches
Filter Type on CC 83 and Slope on CC 106 are switches, like Osc Sync on CC 110 and the arpeggiator On and Latch.

Osc 1	8
Range	70
Coarse	27
Fine	26
PW	74
PW Env	72
PW LFO 2	73
Mod Env	71
LFO 1	28

Osc 2	8
Range	75
Coarse	30
Fine	29
PW	79
PW Env	77
PW LFO 2	78
Mod Env	76
LFO 1	31

Sub & Sync	4	
Sub Wave		80
Sub Oct		81
Bend Amt		107
Osc Sync	switch	110

Mixer	6
Osc 1	20
Osc 2	21
Sub	22
Noise	23
Ring Mod	24
External	25

Filter	8	
Cutoff		16
Reso		82
Overdrive		114
Env Depth		85
LFO 2		17
Shape		84
Type	switch	83
Slope	switch	106

Amp Env	5
Attack	90
Decay	91
Sustain	92
Release	93
Velocity	112

Mod Env	5
Attack	102
Decay	103
Sustain	104
Release	105
Velocity	113

LFO	6
1 Rate	18
1 Delay	86
1 Wave	88
2 Rate	19
2 Delay	87
2 Wave	89

Effects	3
Distortion	94
Filter Mod	115
VCA Limit	95

Arp	6	
On	switch	108
Latch	switch	109
Rhythm		119
Note Mode		118
Octaves		111
Swing		116

Perform	3	
Volume		7
Portamento		5
Sustain	switch	64

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia