Drum machine

Roland TR-09

39 parameters · 5 sections · plain CC, no NRPN · transcribed from the maker's manual

Channel 10
The 909 as a module, on channel 10 by default.

Kick and snare
Each instrument carries tune, decay and level. The kick adds BD Attack on CC 21 and BD Comp on CC 22, the snare SD Comp on CC 27 and SD Tone on CC 28.

Tune	11
BD Tune	20
SD Tune	25
LT Tune	46
MT Tune	49
HT Tune	52
RS Tune	55
HC Tune	58
CH Tune	61
OH Tune	80
CC Tune	83
RC Tune	86

Decay	11
BD Decay	23
SD Snappy	26
LT Decay	47
MT Decay	50
HT Decay	53
RS Decay	56
HC Decay	59
CH Decay	62
OH Decay	81
CC Decay	84
RC Decay	87

Level	11
BD Level	24
SD Level	29
LT Level	48
MT Level	51
HT Level	54
RS Level	57
HC Level	60
CH Level	63
OH Level	82
CC Level	85
RC Level	88

Voice	4
BD Attack	21
BD Comp	22
SD Comp	27
SD Tone	28

Play	2
Shuffle	9
Total Accent	71

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia