Groovebox

Sonicware deconstruct MINIMAL

43 parameters · 3 sections · plain CC, no NRPN · transcribed from the maker's manual

Three blocks

Sonicware's chart is a grid of track types, not a list. Here it is three blocks: the first works on any track, the second belongs to track 11, and the last is the pattern itself.

Track 11

Track 11 is the acid voice. It has its own Cutoff on CC 33, Reso on CC 34, Env, Decay, Accent and Drive.

Any track	16
Sound	12
Tune	13
Tone	14
Move	15
Attack	16
Decay	17
To Rvb	18
To Dly	19
Pan	20
Level	21
Rnd Vl	22
Mute switch	23
Sound Bank	24
Octave	42
Swing	43
Swing Reso	44

Track 11	9
Cutoff	33
Reso	34
Env	35
Decay	36
Accent	37
Drive	38
Level	39
Drive Bypass switch	40
Glide Curve	41

Pattern	18
Iso Low	51
Iso Mid	52
Iso Hi	53
Reverb Type	54
Reverb	55
Delay Mix	56
Delay Time	57
Delay Feedback	58
Delay Ping Pong	59
Delay Sync	60
Delay To Reverb	61
MFX Bypass switch	62
MFX Type	63
MFX Prm	64
Pattern Swing	65
Pattern Swing Reso	66
Feel	67
Pattern Level	68

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia