Synth

Sonicware LIVEN 8bit warps

37 parameters · 6 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels
One channel for the whole machine.

Numbered parameters
Synth Parameter 1 to 6, on CC 24 to 29, change meaning with the engine loaded into SYNTH ENGINE. That is why the chart names them by number.

Engine	10
Synth Engine	20
Octave	21
Detune	23
Synth Parameter 1	24
Synth Parameter 2	25
Synth Parameter 3	26
Synth Parameter 4	27
Synth Parameter 5	28
Synth Parameter 6	29
Alias Noise	30

Filter	5	
Filter Active	switch	31
Filter Type		32
Filter Cutoff		33
Filter Reso		34
Filter CO		35

Envelope	4
EG Attack	38
EG Decay	39
EG Sustain	40
EG Release	41

LFO and sweep	5
LFO Rate	36
LFO Pitch	37
Sweep	42
Sweep Speed	43
Sweep Shift	44

FX	5
FX Type	45
FX Speed	46
FX Amount	47
Reverb Type	48
Reverb	49

Sequencer	8
Glide / Arp Type	5
Velocity	22
Gate Time	50
Swing	51
Voice Mode	52
Seq Mode	53
Mem Level	54
Prm Lock	55

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia