Groovebox

Sonicware LIVEN Lofi-12

43 parameters · 7 sections · plain CC, no NRPN · transcribed from the maker's manual

Channels
Pattern controls answer on the pattern channel. Everything else answers on the track's own channel.

Not the XT
This is the original Lofi-12. The Lofi-12 XT is a different machine with its own, much larger map.

Pattern	7
Velocity	5
FX Type	20
FX Speed	21
FX Amount	22
Ptn Level	23
Seq Mode	24
Bank	25

Sample	7
Sample	27
Octave	28
12bit	29
Start	30
Laid-back	31
Pitch	32
Attack	50

Filter	5
Filter Type	37
Filter Cutoff	38
Filter Reso	39
Filter Env Depth	40
Filter Env Time	41

LFO	5
LFO Shape	42
LFO Delay	43
LFO Rate	44
LFO Pitch	45
LFO Filter Depth	46

Reverb	4
To Reverb	33
Reverb Type	34
Reverb Mix	35
Line In to Reverb	36

Sweep	4
Sweep	51
Sweep Speed	52
Sweep Range	53
Sweep Curve	54

Track	11
Release & Gate	47
Dice	48
Swing	49
Voice Mode	55
Voice Adj	56
Transpose	57
Random Step	58
Prm Lock	59
Track Level	60
Track Pan	61
Track Mute	62

These controls as knobs on your iPhone or iPad
Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia