Synth

Yamaha reface YC

10 parameters · 3 sections · plain CC, no NRPN · transcribed from the maker's manual

Before you send

Turn MIDI Control on in the settings first.

The drawbars are the map

Each footage has a number of its own, from the 16' drawbar on CC 102 upward. Moving them from a controller is the closest thing to playing the panel.

Drawbars	8
Footage 16'	102
Footage 5 1/3'	103
Footage 8'	104
Footage 4'	105
Footage 2 2/3'	106
Footage 2'	107
Footage 1 3/5'	108
Footage 1 1/3'	109

Oscillator and mix	1
Wave	80

Play	1
Rotary Speed	19

These controls as knobs on your iPhone or iPad

Sequentia has this chart built in, with a looper for knob movement and tempo-locked LFOs on any CC.

synthycraft.com/l/sequentia